






SKU	SIZE	COMPATIBLE ACCESS POINTS
 <p data-bbox="284 465 453 499">33-AP-CVR</p>	<p data-bbox="676 454 914 488">8.8 x 8.8 x 2.1 in.</p> <p data-bbox="612 495 978 528">(223.5 x 223.5 x 53.3 mm)</p>	<p data-bbox="1050 454 1485 528">Cisco 2600, 2700, 3500, 3600, 3700, 9115</p>
 <p data-bbox="284 705 507 739">33-AP335-CVR</p>	<p data-bbox="676 694 914 728">9.2 x 9.3 x 1.9 in.</p> <p data-bbox="612 734 978 768">(233.7 x 236.2 x 48.3 mm)</p>	<p data-bbox="1050 694 1485 768">Aruba AP305, AP315, AP325, AP335, AP345, AP515</p>
 <p data-bbox="284 945 528 978">33-AP3800-CVR</p>	<p data-bbox="676 934 914 967">8.9 x 8.9 x 2.3 in.</p> <p data-bbox="612 974 978 1008">(226.1 x 226.1 x 58.4 mm)</p>	<p data-bbox="1050 896 1485 969">Cisco 1830, 1850, 2800, 3800, 9117, 9120</p> <p data-bbox="1094 976 1433 1041">Ubiquiti UAP-ACHD-US Huawei AP7060DN</p>
 <p data-bbox="284 1184 576 1218">33-COAP4800-CVR</p>	<p data-bbox="639 1173 951 1207">10.09 x 10.09 x 2.7 in.</p> <p data-bbox="612 1214 978 1247">(256.3 x 256.3 x 68.6 mm)</p>	<p data-bbox="1185 1189 1350 1223">Cisco 4800</p>
 <p data-bbox="284 1424 576 1458">33-COAP9130-CVR</p>	<p data-bbox="651 1413 940 1447">9.26 x 9.26 x 2.02 in.</p> <p data-bbox="612 1453 978 1487">(235.2 x 235.2 x 51.3 mm)</p>	<p data-bbox="1185 1429 1350 1462">Cisco 9130</p>
 <p data-bbox="284 1664 496 1697">33-MR53-CVR</p>	<p data-bbox="671 1653 922 1686">10.9 x 6.7 x 1.7 in.</p> <p data-bbox="612 1693 978 1727">(276.9 x 170.1 x 43.2 mm)</p>	<p data-bbox="1023 1668 1513 1702">Meraki MR32, MR42, MR52, MR53</p>



33-MR56-CVR

13.2 x 5.9 x 2 in.  
(335.3 x 149.9 x 50.8 mm)


Meraki MR45, MR46, MR55, MR56



33-VCVR-1

8.85 x 8.85 x 1.84 in.  
(224.8 x 224.8 x 46.7 mm)

Cisco 9115i and 9120i



33-VCVR-10102

10 x 10 x 2.33 in.  
(254 x 254 x 59.2 mm)

Aruba AP535 & similar sized APs



33-VCVR-18125

18 x 12 x 5 in.  
(457.2 x 304.8 x 127 mm)

Larger sized APs